

# RFID Headlight Sticker Installation Guide

## Before You Begin

- Ensure your headlight is clean and dry.
- The HeadlightSticker™ is designed for external use only.
- Do not place the sticker on metal or tinted areas.
- Handle with care – **Do Not Bend** the sticker at any time.

## Step by Step Installation

1.

### Clean the Surface

Use a lint-free cloth and gentle cleaner to thoroughly clean and dry the headlight where the sticker will be applied. This ensures proper adhesion.

2.

### Prepare the Sticker

**Do Not Bend** the sticker.

- Place the sticker face down on a flat surface.
- Hold the sticker by the edges to avoid touching the adhesive side.
- Gently peel the backing away from the sticker (not the other way around).

3.

### Apply the Sticker

- Mount the sticker horizontally, on the headlight only (not on metal or glass).
- Ensure it's placed at least 2 inches away from any metal trim or part of the vehicle.
- Once positioned, press down firmly across the entire sticker to secure it.



## Important Notes

The RFID tag may not scan if installed incorrectly or on improper surfaces.

Avoid repositioning the sticker once applied — this will damage it. Stickers are designed to break upon removal.

For best performance, install during mild temperatures (not too hot or cold).



**For More Tips** – Scan the QR code for more tips.